

Updating xml-file




OSRAM

Interface Software for Windows


1 Updating the xml-file

How to exchange the xml-file.

Open the Interface software.




Go to the about page.




Press the button Open Files.

OSRAM Interface Software



Choose the folder XML



Replace the file ProgramsNov2014.xml with the new file, which has the same name.

Close Interface Software and start it up again to see the new lamps and programs.